Coda / CDAGMXXXX and CDAGNXXXX

Disassembly Instructions and Recycling




Required Tools, Time, and Personnel:

Phillip's head screw driver Disassembly time estimated to take 15 minutes.


(Optional) Putty knife Three person minimum for safe operation.

Suction Cup Lifter


Step 1: Remove Coda Glassboard from wall.



Step 2: Remove the z-bars from the wall.



Step 3: (Optional) If the glassboard has a rear magnetic panel pry one corner away from the glass using a putty knife. Continue to separate the magnetic panel from the glassboard until fully separated.



Coda / CDAGMXXXX and CDAGNXXXX

Disassembly Instructions and Recycling



Recycling Guidelines:

- Steel Common metals can be recycled at local scrap yards and nearly all recycling centers.
- Tempered glass Tempered glass can be recycled through an annealing process, however this is often cost prohibitive. If you are not in an area with a tempered glass recycling facility please consult local construction companies to see if they accept tempered glass for use in large volume construction applications such as roadways.
- Miscellaneous Accessories consult local guidelines to determine if you are able to recycle composite plastics at your recycling centers.

